



PIC00001

take off the mirrors



PIC00002

take off the clutch lever



PIC00003

take off the toolbag



PIC00004

take all the little brackets that hold cables to the handlebars.



PIC00005

remove the master cylinder



PIC00006

keep the master cylinder upright so we can stop later.



PIC00007

more cable thingies



PIC00008

screws out of housing by throttle



PIC00009

take the throttle off.



PIC00010

bare nekkid handlebars



PIC00011

already took one of these - bare nekkid handlebars.



PIC00012

cut off the welded part of the risers with a swift chopping motion and a BIG axe.

(just kidding :-)



PIC00013

new risers sorta sitting in place



PIC00014

start cutting off the welded part with a hacksaw. no work bench so I just sat on the floor.



PIC00015

one riser gone.



PIC00016

both risers gone.



PIC00017

grind a little with a dremel



PIC00018

see the sparks?



PIC00019

more grinding - this was time consuming.





PIC00021

much more sparks - all is good!



PIC00022

everything grinded off - some buggaring, but hey, I did it sitting on the floor and it doesn't show once they are installed.



PIC00023

everything back together - front veiw



PIC00024

sitting view



PIC00025

side view



PIC00026

rear view.