

**FRONT WHEEL/SUSPENSION/STEERING**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS
Clutch lever bracket holder bolt	2	6	12 (1.2, 9)	page 14-10
Clutch lever pivot bolt	1	6	1.0 (0.1, 0.7)	
Clutch lever pivot nut	1	6	5.9 (0.6, 4.3)	NOTE 6
Handlebar mounting nut	2	12	54 (5.5, 40)	
Front brake disc bolt	6	8	42 (4.3, 31)	
Spoke	52	BC4	3.9 (0.4, 2.9)	
Front axle	1	18	74 (7.5, 54)	NOTE 3
Front axle pinch bolt	2	8	22 (2.2, 16)	
Fork center socket bolt	2	10	29 (3.0, 22)	NOTE 3
Fork cap	2	38	22 (2.2, 16)	
Fork cover bolt	2	6	12 (1.2, 9)	page 14-28
Fork cover bolt	2	8	26 (2.7, 20)	
Fork top bridge pinch bolt	2	8	26 (2.7, 20)	
Fork bottom bridge pinch bolt	2	10	49 (5.0, 36)	
Steering top thread	1	26	-	page 14-28
Steering top thread lock nut	1	26	-	page 14-28
Steering stem nut	1	24	103 (10.5, 76)	

**REAR WHEEL/BRAKE/SUSPENSION**

ITEM	Q'TY	THREAD DIA. (mm)	TORQUE N-m (kgf-m, lbf-ft)	REMARKS
Spoke	52	BC4	3.9 (0.4, 2.9)	NOTE 7
Rear axle nut	1	18	88 (9.0, 65)	
Rear axle pinch bolt	1	8	26 (2.7, 20)	
Rear brake stopper arm nut	1	8	22 (2.2, 16)	
Rear brake arm pinch bolt	1	8	28 (2.9, 21)	NOTE 6
Rear shock absorber upper mounting bolt	2	8	26 (2.7, 20)	
Rear shock absorber lower mounting bolt (right side)	1	10	34 (3.5, 25)	
Stopper plate bolt	5	6	20 (2.0, 14)	
Swingarm left pivot bolt	1	30	103 (10.5, 76)	page 15-26
Swingarm right pivot bolt	1	30	-	
Swingarm right pivot bolt lock nut	1	30	103 (10.5, 76)	